

Items Supplied >

- 1 – Freeway Bar
- 2 – 10mm X 20mm Button Head Bolts
- 2 – 10mm X 20mm Hex Bolts
- 4 – 10mm Flat Washers

Application >

- SUZUKI VOLUSIA 800 01-04
- SUZUKI C50 05-14
- SUZUKI M50 05-14

Instruction Manual >

01-1325

Page 1 of 1

*** Read all instructions carefully and completely before installing your new Cobra® freeway bar ***

1. Remove the (2) rubber plugs from the threaded holes of front frame rails just below the plastic steering head covers.
2. Mount the top end of freeway bar (open end) to the holes mentioned in step #1 using (2) supplied button head bolts and flat washers. Leave loose, do not tighten. (Note the bar will mount in front of the plastic frame covers.)
3. Mount lower mounts to the threaded holes located on the inside of lower frame rails using (2) supplied hex bolts and flat washers.
4. Tighten all bolts both top and bottom

NOTE: If any bolt becomes hard to turn before it is tightened all the way it may be necessary to chase threads with a 10mm (1.25) metric tap

Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**