

Items Supplied >

- 1 – Luggage Rack
- 4 – M8 x 35 mm Buttonhead Cap Screw
- 4 – M8 Nylock Nut

Application(s) >

KAWASAKI VN900LT 2006 - 2014

Instruction Manual >

02-4468

Page 1 of 1

Read all instructions carefully before installing your new Cobra® product!

1. Remove the M8 bolts securing the sissybar to the side mount plate on the right side only. **CAUTION:** remove only one side of the mounting bolts at a time to prevent the sissybar from rotating or falling.
2. Place the luggage rack between the sissybar, align the holes, and install (2) supplied M8 x 35 mm buttonhead screws through the side mount plate, sissybar, luggage rack and supplied M8 Nylock nuts, **DO NOT TIGHTEN AT THIS TIME.** Be sure to hold the buttonhead screws tight with an Allen wrench while installing the M8 Nylock nut, to prevent it from backing out.
3. On the left side remove the M8 bolts securing the sissybar to the side mount plate on the left side.
4. Install (2) supplied M8 x 35 mm buttonhead screws through the side mount plate, sissybar, luggage rack and supplied M8 Nylock nuts, **DO NOT TIGHTEN AT THIS TIME.**
5. Make sure the rack is aligned horizontally with the rest of the motorcycle and tighten the screws and nuts to factory specifications.

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**