

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 16mm Buttonhead Bolts

Application(s) >

HONDA SPIRIT 750 C2 07-09, 12-14
HONDA PHANTOM 750 10-19

Instruction Manual >

02-4611/02-5111/02-5611

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 16mm Button Head bolts then tighten all hardware.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 16mm Buttonhead Bolts

Application(s) >

- HONDA SPIRIT 750 C2 07-09. 12-14
- HONDA PHANTOM 750 10-19

Instruction Manual >

02-4611/02-5111/02-5611

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 16mm Button Head bolts then tighten all hardware.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019
11/08

REV. A

Anything's Possible.®