

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button head Bolts
- 4 - 8mm x 65mm Button head Bolts
- 2 - Thick Spacers
- 2 - Thin Spacers

Application(s) >

Suzuki Volusia 800 01-04
Suzuki Boulevard M50 05-14
Suzuki Boulevard C50 05-14

Instruction Manual >

02-4825/02-5325/02-5825

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the two (2) rear bolts on each fender rail.
2. Install the brackets with the bent portion (part number) toward the inside using the supplied 8mm x 65mm bolts and spacers, brackets will mount on the outside of fender rail with the thick spacer in the rear & the thin spacer in the front.
3. Install the sissy bar to the brackets using the supplied 8mm x 16mm bolts and tighten. Tighten all mounting hardware to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button head Bolts
- 4 - 8mm x 65mm Button head Bolts
- 2 - Thick Spacers
- 2 - Thin Spacers

Application(s) >

Suzuki Volusia 800 01-04
Suzuki Boulevard M50 05-14
Suzuki Boulevard C50 05-14

Instruction Manual >

02-4825/02-5325/02-5825

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the two (2) rear bolts on each fender rail.
2. Install the brackets with the bent portion (part number) toward the inside using the supplied 8mm x 65mm bolts and spacers, brackets will mount on the outside of fender rail with the thick spacer in the rear & the thin spacer in the front.
3. Install the sissy bar to the brackets using the supplied 8mm x 16mm bolts and tighten. Tighten all mounting hardware to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019
11/08

REV. A

Anything's Possible.®