

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - 8mm x 40mm Button Head Bolts
- 2 - 10mm x 40mm Button Head Bolts
- 4 - 8 x 20 Button Head Bolts
- 2 - Small Spacers
- 2 - Large Spacers

Application(s) >

- Honda VTX1800C 02-07
- Honda VTX1300C 04-06
- Honda VTX1800F 05-08

Instruction Manual >

02-7650 / 02-8650

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. Note: Install one side at a time

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10x40mm bolt thru the bracket, spacer and into the fender rail. Insert the M8x40mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four supplied 8mm x 20mm Button Head bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
07/08

Anything's Possible.

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - 8mm x 40mm Button Head Bolts
- 2 - 10mm x 40mm Button Head Bolts
- 4 - 8 x 20 Button Head Bolts
- 2 - Small Spacers
- 2 - Large Spacers

Application(s) >

- Honda VTX1800C 02-07
- Honda VTX1300C 04-06
- Honda VTX1800F 05-08

Instruction Manual >

02-7650 / 02-8650

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. Note: Install one side at a time

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10x40mm bolt thru the bracket, spacer and into the fender rail. Insert the M8x40mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four supplied 8mm x 20mm Button Head bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
07/08

Anything's Possible.