



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

Caliper Cap(s)

Application(s) >

All Brake Calipers

Instruction Manual >

1. Thoroughly clean the outside of the caliper surface with contact cleaner where the caliper cap will be attached.
2. Peel the backing off of the two sided high bond adhesive strip(s) and carefully place the caliper cap into position on the brake caliper.
3. Press firmly on the caliper cap for one minute. **Do not pull on the caliper cap to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0023 REV. A

04/01

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

Caliper Cap(s)

Application(s) >

All Brake Calipers

Instruction Manual >

1. Thoroughly clean the outside of the caliper surface with contact cleaner where the caliper cap will be attached.
2. Peel the backing off of the two sided high bond adhesive strip(s) and carefully place the caliper cap into position on the brake caliper.
3. Press firmly on the caliper cap for one minute. **Do not pull on the caliper cap to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0023 REV. A

04/01

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

Caliper Cap(s)

Application(s) >

All Brake Calipers

Instruction Manual >

1. Thoroughly clean the outside of the caliper surface with contact cleaner where the caliper cap will be attached.
2. Peel the backing off of the two sided high bond adhesive strip(s) and carefully place the caliper cap into position on the brake caliper.
3. Press firmly on the caliper cap for one minute. **Do not pull on the caliper cap to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0023 REV. A

04/01

**Anything's Possible.**