



23801 E. La Palma Ave., Yorba Linda, CA 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 1 - Set Of Floorboards And Mounts
- 4 - 8mm x 25mm Allen Bolts

**Application(s) >**

V-STAR 1100 99-09

**Instruction Manual >**

06-3740/06-4740

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard mounts into that location using the 8mm x 25mm allen bolts provided. Torque to factory specification.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
04/01

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, CA 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 1 - Set Of Floorboards And Mounts
- 4 - 8mm x 25mm Allen Bolts

**Application(s) >**

V-STAR 1100 99-09

**Instruction Manual >**

06-3740/06-4740

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard mounts into that location using the 8mm x 25mm allen bolts provided. Torque to factory specification.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
04/01

**Anything's Possible.**