

Items Supplied >

- 1 – Front Muffler
- 1 – Rear Muffler
- 1 – Rear Head Pipe
- 1 – Hose Clamp
- 1 – 5/16" x 3/4" Hex Bolt
- 1 – 5/16" Lock Washer
- 1 – 5/16" Flat Washer
- 2 – 2" Heat Shields

Application >

SUZUKI INTRUDER 1400 87-04
SUZUKI S83 05-09

Instruction Manual >

3265

Page 1 of 1

1. Remove stock exhaust system.
2. Install rear head pipe first and **FINGER TIGHTEN** all nuts and bolts.
3. Install front pipe and **FINGER TIGHTEN** all nuts and bolts.
4. Install second half of rear pipe (slide over head pipe and clamp) and bolt to front pipe using supplied hardware.
5. Check for proper fit and alignment then secure all bolts.
6. Install head pipe cover on rear head pipe using supplied clamps.
7. Install front heat shield where necessary. Be careful not to scratch your chrome during installation of the heat shields.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-3165.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*