

Items Supplied >

- 1 - Front Muffler
- 1 - Rear Muffler
- 1 - Mounting Bracket Assembly w/hardware
- 2 - #268-55 T-Bolt Clamps

Application >

YAMAHA ROADSTAR 1600/1700 99-10

Instruction Manual >

2171SC

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

Read all instructions carefully and completely before installing your new exhaust system

1. Remove the stock mufflers leaving head pipes in place.
2. Install the supplied mounting bracket on top of the original mounting bar with the bend going out and down using the two original mounting bolts.
3. Slip the rear muffler body onto the head pipe. Mount the muffler body bracket to the rear slotted hole on the mounting bracket using the supplied nut, bolt, and washers. Tighten the T-bolt clamp then the mounting hardware.
4. Slip the front muffler body onto the head pipe. Mount the muffler body bracket to the front slotted hole on the mounting bracket using the supplied nut, bolt, and washers. Tighten the T-bolt clamp then the mounting hardware.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra. **RoadStar 1600 ('99-'03) part #92-2271, RoadStar 1700 ('04-'07) part #92-2272.** It is recommended that you install a Cobra Fi2000® Digital Fuel Processor with your Cobra exhaust system for the **('08-'10) Roadstar 1700 part #92-1771CL.**

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*