

## Items Supplied >

1 - Backrest Insert

## Application(s) >

All Cobra Short & Mini Sissy Bars

## Instruction Manual >

02-5036/02-5038

1. Remove the three (3) bolts that secure backrest pad and set aside, these will be re-used in step 3.
2. Align the three bolt holes of the sissy bar insert with the three tabs on the back side of sissy bar (logo facing out).
3. While holding the pad and insert in place, begin installing the bolts removed in step 1, before tightening completely make sure both pad and insert are properly aligned.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
02/01

**Anything's Possible.**

## Items Supplied >

1 - Backrest Insert

## Application(s) >

All Cobra Short & Mini Sissy Bars

## Instruction Manual >

02-5036/02-5038

1. Remove the three (3) bolts that secure backrest pad and set aside, these will be re-used in step 3.
2. Align the three bolt holes of the sissy bar insert with the three tabs on the sissy bar (logo facing out).
3. While holding pad and insert in place, begin installing three (3) bolts removed in step 1, before tightening completely make sure both pad and insert are properly aligned.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
02/01

**Anything's Possible.**