



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

### Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Bolts
- 2 - 8mm x 40mm Button Head Bolts
- 2 - 8mm x 30mm Button Head Bolts
- 4 - 8mm Flat Washers

### Application(s) >

ACE 750 98-02

### Instruction Manual >

02-4615/02-5115/02-5615

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the two (2) rear bolts on each fender rail.
2. Install the brackets with the supplied washers between the bracket and the fender rail and secure using the two (2) 8mm x 40mm button head bolts in the front and the two (2) 8mm x 30mm button head bolts in the rear.
3. Install the sissy bar to the brackets using the four (4) supplied 8mm x 16mm Button Head bolts then tighten all hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

11/01

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

### Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Bolts
- 2 - 8mm x 40mm Button Head Bolts
- 2 - 8mm x 30mm Button Head Bolts
- 4 - 8mm Flat Washers

### Application(s) >

ACE 750 98-02

### Instruction Manual >

02-4615/02-5115/02-5615

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the two (2) rear bolts on each fender rail.
2. Install the brackets with the supplied washers between the bracket and the fender rail and secure using the two (2) 8mm x 40mm button head bolts in the front and the two (2) 8mm x 30mm button head bolts in the rear.
3. Install the sissy bar to the brackets using the four (4) supplied 8mm x 16mm Button Head bolts then tighten all hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

11/01

**Anything's Possible.**