



**Items Supplied >**

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Screws
- 2 - M10 x 60mm Button Head Screws
- 2 - M10 x 65mm Button Head Screws
- 4 - Flat Washers

**Application(s) >**

Suzuki Boulevard C109R 08-09

**Instruction Manual >**

02-4850 / 02-5350 / 02-5850

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time**

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10 x 60mm bolt thru the bracket, washer and into the fender rail. Insert the M10 x 65mm bolt thru the bracket, washer and into the rear hole of the fender rail. **Do not tighten at this time.**
2. Repeat Step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm Button Head Screws
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. B

06/08

**Anything's Possible™**



**Items Supplied >**

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Screws
- 2 - M10 x 60mm Button Head Screws
- 2 - M10 x 65mm Button Head Screws
- 4 - Flat Washers

**Application(s) >**

Suzuki Boulevard C109R 08-09

**Instruction Manual >**

02-4850 / 02-5350 / 02-5850

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time**

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10 x 60mm bolt thru the bracket, washer and into the fender rail. Insert the M10 x 65mm bolt thru the bracket, washer and into the rear hole of the fender rail. **Do not tighten at this time.**
2. Repeat Step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm Button Head bolts.
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A

06/08

**Anything's Possible™**