

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

## Items Supplied >

- 1 – LEFT SADDLEBAG SUPPORT
- 1 – RIGHT SADDLEBAG SUPPORT
- 2 – BOLT, M8 X 40mm BUTTONHEAD
- 2 – BOLT, M8 X 50mm BUTTONHEAD
- 4 – WASHER, 5/16" FLAT

## Application(s) >

[www.cobrausa.com](http://www.cobrausa.com)

YAMAHA STRYKER

2011-2015

## Instruction Manual >

02-6270

**Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove your stock fender rail bolts on left side and discard.
2. Place a supplied washer between each saddlebag support bushing and the fender rail, then insert the longer supplied M8 x 50mm bolt thru the front and the shorter M8 x 40mm bolt thru the rear. **NOTE:** The upper bend of the saddlebag support should point towards the front.
3. Repeat Steps 1 & 2 on the right side of the motorcycle.
4. Torque bolts to factory specifications.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
06/11

***Anything's Possible.®***

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

## Items Supplied >

- 1 – LEFT SADDLEBAG SUPPORT
- 1 – RIGHT SADDLEBAG SUPPORT
- 2 – BOLT, M8 X 40mm BUTTONHEAD
- 2 – BOLT, M8 X 50mm BUTTONHEAD
- 4 – WASHER, 5/16" FLAT

## Application(s) >

YAMAHA STRYKER 2011-2015

## Instruction Manual >

02-6270

**Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove your stock fender rail bolts on left side and discard.
2. Place a supplied washer between each saddlebag support bushing and the fender rail, then insert the longer supplied M8 x 50mm bolt in the front and the shorter M8 x 40mm bolt in the rear. **NOTE:** The upper bend of the saddlebag support should point towards the front.
3. Repeat Steps 1 & 2 on the right side of the motorcycle.
4. Torque bolts to factory specifications.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
06/11

***Anything's Possible.®***