

COBRA

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 4 – Bungee Knobs
- 2 – Screws, M8 x 60mm Buttonhead
- 2 – Screws, M8 x 65 mm Buttonhead

Application(s) >

YAMAHA STRYKER

2011-2015

Instruction Manual >

02-7270

1. Remove the stock front M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 65 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
2. Remove the stock rear M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 60 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
3. With all components aligned and installed tighten the buttonhead screws to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. B
04/11

Anything's Possible®



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 4 – Bungee Knobs
- 2 – Screws, M8 x 60 mm Buttonhead
- 2 – Screws, M8 x 65 mm Buttonhead

Application(s) >

YAMAHA STRYKER

2011-2015

Instruction Manual >

02-7270

1. Remove the stock front M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 65 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
2. Remove the stock rear M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 60 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
3. With all components aligned and installed tighten the buttonhead screws to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*