

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissybar with Pad
- 2 - Left and Right Mounting Brackets
- 2 - 8mm x 50mm; 2 - 8mm x 55 mm Button Head Bolts
- 4 - 8mm x 20mm Button Head Bolts
- 2 - Long Spacers (.510)
- 2 - Short Spacers (.300)

Application(s) >

Yamaha Roadliner 06-14

Instruction Manual >

02-7760 / 02-8760

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove (2) M8 bolts from left side fender rail/rear fender and discard. Install left sissybar mounting bracket (part number should face inward), by inserting the supplied M8 x 55 mm bolt through bracket, supplied longer spacer and into front hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Install supplied M8 x 50 mm bolt through rear mounting hole of bracket, shorter spacer, fender rail and into fender, (**DO NOT TIGHTEN.**) Repeat for right side bracket.
2. Install the sissy bar between brackets using the supplied (4) M8 x 20 mm button head bolts.
3. Align sissybar and tighten all hardware. Torque all bolts to appropriate values.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissybar with Pad
- 2 - Left and Right Mounting Brackets
- 2 - 8mm x 50mm; 2 - 8mm x 55 mm Button Head Bolts
- 4 - 8mm x 20mm Button Head Bolts
- 2 - Long Spacers (.510")
- 2 - Short Spacers (.300")

Application(s) >

Yamaha Roadliner 06-14

Instruction Manual >

02-7760 / 02-8760

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove (2) M8 bolts from left side fender rail/rear fender and discard. Install left sissybar mounting bracket (part number should face inward), by inserting the supplied M8 x 55mm bolt through bracket, supplied longer spacer and into front hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Install supplied M8 x 50 mm bolt through rear mounting hole of bracket, shorter spacer, fender rail and into fender, (**DO NOT TIGHTEN.**) Repeat for right side bracket.
2. Install the sissy bar between brackets using the supplied (4) M8 x 20 mm button head bolts.
3. Align sissybar and tighten all hardware. Torque all bolts to appropriate values.

***Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**