

## Items Supplied >

- 1 – LIGHTBAR ASSEMBLY
- 2 – M8 X 20mm BUTTONHEAD BOLTS
- 2 – SPACERS
- 1 – 20" BLACK POWER WIRE W/ CONNECTOR
- 1 – QUICK SPLICE CONNECTOR (BLUE)
- 3 – ZIPTIES

## Application >

YAMAHA RAIDER 2008-2014

## Instruction Manual >

04-0265

Page 1 of 1

**Read your installation instructions completely before beginning. This lightbar can be installed in just a few minutes using common tools. It is recommended however, that a qualified mechanic or technician install this product.**

1. Remove (2) screws from headlight housing. Remove headlight from housing, unplug and set aside.
2. Remove the (2) lower M8 buttonhead bolts from the front of the lower triple clamp and discard.
3. Install your new Cobra lightbar by inserting the (2) supplied M8 buttonhead bolts through the lightbar mount, supplied spacers and into triple clamp where the bolts were removed in Step 2. Make sure lightbar is properly aligned and level then tighten bolts.
4. Route the left spotlight wire under the lightbar and to the switch, take the right spotlight wire and twist together with the left one. Insert the (2) twisted together wires into supplied push on terminal and crimp with a crimping tool. Connect this to one of the poles on the lightbar switch. (it doesn't matter which one.)
5. Connect the 20" power wire to the remaining pole on the lightbar switch. Route the power wire through the back of the headlight housing. Pull any loose slack out of the wire and using the (3) supplied zip ties wrap spotlight and power wires to the lightbar.
6. Find the Blue running light/turn signal wire inside headlight housing. Connect the black power wire from the lightbar switch using the supplied (blue) quick splice connector.
7. Check to make sure the spotlights work properly. Plug headlight back in, and reinstall headlight to housing with (2) screws removed in Step 1.
8. Check to make sure your handlebars turn from lock to lock without any stretching or binding of any wires. Check the alignment of all your lighting. Make sure everything is in proper working order before riding your motorcycle.

**\* Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**