

## Items Supplied >

- 1 – ASSEMBLED LIGHTBAR
- 2 – SPACER, BLACK
- 3 – CABLE TIES 4" BLACK 18# TEST
- 1 – WIRE QUICK SPLICE CONNECTOR
- 2 – WIRE TERMINALS
- 1 – WIRE 18 GAGE BLACK 20" LENGTH

## Application(s) >

KAWASAKI VN1700 CLASSIC/LT 09-13

## Instruction Manual >

04-0465

Page 1 of 1

### Read all instructions carefully before installing your new Cobra® product!

1. Remove the (2) Phillips head screws from headlight and set aside. Remove headlight from housing, unplug and set aside.
2. Unplug turn signal connectors inside headlight housing, and note which stock female connectors belong to left and right turn signals. Remove the (2) M6 bolts from turn signal bar and set bolts aside.
3. Install your new Cobra lightbar by inserting the (2) M6 bolts removed from Step 2 through the lightbar mount, supplied spacers and into the stock mounting location, tighten to factory torque specifications. Align spotlights and turn signals then tighten all hardware firmly.
4. Route the new turn signal wires along the lightbar tube and through back of headlight. Install left turn signal connector into the stock female black connector in the same manner in which the stock connector was removed. Repeat with right turn signal using the stock female gray connector.
5. Route the left spotlight wire under the lightbar towards the lightbar switch, take the right spotlight wire and twist together with the left one. Insert the two (twisted together) wires into the supplied push on terminal and crimp with a crimping tool. Connect this to one of the poles on the lightbar switch, it does not matter which one.
6. Connect the 20" power wire to the remaining pole on the lightbar switch. Route the power wire along the lightbar tube and through the back of the headlight housing. Loosely pull slack out of the wire and using the 3 supplied zip ties secure spotlight, turn signal, and power wires to the lightbar.
7. Locate the yellow wire accessory lead with the large double barrel wire connector inside the headlight housing. Connect the black power wire from the lightbar switch to the yellow accessory wire using the supplied blue quick splice connector.
8. Check to make sure spotlights and turn signals work properly. Reconnect headlight plug and reinstall headlight into the housing with the (2) Phillips screws removed in Step 1.
9. Check to make sure your handlebars turn from lock to lock without any stretching or binding in any of the wires. Check the alignment of all your lighting. Make sure everything is in proper working order before riding the vehicle.

*\* Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*