

Items Supplied >

- 1 – Headlight Visor
- 1 – Headlight Visor Circlip

Application(s) >

- 04-2000 HEADLIGHT VISOR 5 3/4"
- 04-2001 HEADLIGHT VISOR 5 3/4" MAGNA
- 04-2002 HEADLIGHT VISOR 7 1/2" 750 ACE
- 04-2003 HEADLIGHT VISOR 7 1/2" MARAUDER
- 04-2005 HEADLIGHT VISOR 7 1/2"
- 04-2007 HEADLIGHT VISOR V-STAR CUSTOM

Instruction Manual >

04-2000/2001/2002/2003/2005/2007

Page 1 of 1

Read all instructions carefully and completely before installing. It is recommended that a qualified mechanic or technician install this product.

1. Mark the top center of headlight rim with masking tape. This will help center the visor when you mount it to the headlight rim.
2. Remove headlight rim with headlight from headlight housing. Remove the headlight from headlight rim making note of how it comes apart.
3. Install visor and install snap ring. Make sure that the point at the upper portion of the snap ring is in contact with the center tab on the visor.

NOTE: Make sure that the snap ring is not hitting any of the welded tabs on the inside of the headlight rim. Then push the ring as close to the front as possible.

4. Once the visor is mounted, hold the assembly so that you can view it from the side. If necessary adjust the angle of the visor by bending the tabs to achieve the proper alignment.
5. Now re-install the headlight into the rim. Then re-install the complete assembly back into the headlight housing.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*