

07 DL 714 (00 0100 E... 714 (00 E01/

Items Supplied > 2 - Cable Ties 1 - Drive Shaft Cover VTX1800C/R/S 02-UP VTX1800N 04-UP VTX1800F 05-UP Instruction Manual > 06-0650 Before installing your Cobra Drive Shaft cover read all instructions carefully 1. Place the cable ties through the tabs on the backside of the drive shaft cover. 2. Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the motorcycle. 3. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not inter the tire. * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while the liftlence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. COCORRECA 23801 E. La Palma Ave., Yorba Linda. Ca 92887 Ph. 714.692.8180 Fax, 714.692			
 Before installing your Cobra Drive Shaft cover read all instructions carefully Place the cable ties through the tabs on the backside of the drive shaft cover. Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the motorcycle. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not inter the tire. Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle whit the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. 			
 Place the cable ties through the tabs on the backside of the drive shaft cover. Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the motorcycle. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not inter the tire. Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle whit the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. 			
 Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the motorcycle. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not inter the tire. * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle white influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. Manything's Place and the same and the safe and the safe			
 motorcycle. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not inter the tire. Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle white influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. 	Place the cable ties through the tabs on the backside of the drive shaft cover.		
the tire. * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle whi the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. Second Rev. B 7/03 CORRELA			
the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely. COMENT NO. 0019 REV. B 7/03 Anything'S P	ere with		
7/03 Anything's P	e under		
COBRA 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.	ssible.		
COBRA 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.			
COBRA 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.			
23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.			
)16		
Items Supplied > Application(s) >			
2 – Cable Ties VTX1800C/R/S 02-UP	brausa.co		
1 – Drive Shaft Cover VTX1300C/S 02-UP VTX1800N 04-UP	brausa.co		

In	ostruction Manual S	06-0650		
Be	Before installing your Cobra Drive Shaft cover read all instructions carefully			
1.	1. Place the cable ties through the tabs on the backside of the drive shaft cover.			
2.	Slide Cobra drive shaft cover over drive shaft with the expanded end of the part toward the rear of the			

- motorcycle.3. Check alignment of part then tighten the cable ties. Cut off excess and make sure cable ties do not interfere with
- the tire.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.