

COBRA[®]

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 – DRIVE BELT GUARD
- 1 – SPACER
- 1 – 6mm x 12mm BUTTONHEAD BOLT
- 1 – 6mm x 20mm BUTTONHEAD BOLT

Application(s) >

www.cobrausa.com

YAMAHA STRYKER

2011-2014

Instruction Manual >

06-0770

Your drive belt guard will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new drive belt guard.

1. Remove the hardware securing the stock belt guard and discard.
2. Install your belt guard by inserting the supplied 6mm x 20mm bolt into the front mounting hole of the belt guard, through the spacer and into the swingarm where the stock front bolt was removed.
3. Insert the 6mm x 12mm bolt through the rear mounting hole of the belt guard and into the swingarm where the stock rear lower bolt was removed. Tighten all bolts to their appropriate values.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A
04/11

Anything's Possible.[®]

COBRA[®]

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – DRIVE BELT GUARD
- 1 – SPACER
- 1 – 6mm x 12mm BUTTONHEAD BOLT
- 1 – 6mm x 20mm BUTTONHEAD BOLT

Application(s) >

YAMAHA STRYKER 2011-2014

Instruction Manual >

06-0770

Your drive belt guard will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new drive belt guard.

1. Remove the hardware securing the stock belt guard and discard.
2. Install your belt guard by inserting the supplied 6mm x 20mm bolt into the front mounting hole of the belt guard, through the spacer and into the swingarm where the stock front bolt was removed.
3. Insert the 6mm x 12mm bolt through the rear mounting hole of the belt guard and into the swingarm where the stock rear lower bolt was removed. Tighten all bolts to their appropriate values.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A
04/11

Anything's Possible.[®]