



Items Supplied >

- 2 Floorboard Assemblies with Mounts
- 2 8mm x 35mm Hex Bolts
- 2 8mm Nylock Nuts
- 4 5/16" Flat Washers

Application(s) >

Suzuki Marauder 800 97-04

Instruction Manual >

06-3820/06-4820

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

- 1. Remove your original passenger foot pegs from their mounts.
- 2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts.
- 3. Check to make sure that the cotter pins are properly installed and the bolts are tight prior to riding the motorcycle.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A. 04/01

Anything's Possible.

www.cobrausa.com

www.cobrausa.com

COBRA

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

## Items Sunnlied >

- 2 Floorboard Assemblies with Mounts
- 2 8mm x 35mm Hex Bolts
- 2 8mm Nylock Nuts
- 4 5/16" Flat Washers

Annlication(s) >

Suzuki Marauder 800 97-04

## Instruction Manual >

06-3820/06-4820

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floor boards.

- 1. Remove your original passenger foot pegs from their mounts.
- 2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts.
- 3. Check to make sure that the cotter pins are properly installed and the bolts are tight prior to riding the motorcycle.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A