



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

### Items Supplied >

- 4) 6mm x 16mm Allen Head Bolts
- 2) Black Turn Signal Adapters
- 2) 1/4" x 3/8" Button Head Allen Screws
- 1) 18" Wire with Push On Connector
- 1) Push On Connector
- 1) Spare Push On Connector
- 1) Blue Quick Splice Connector

### Application(s) >

ACE TOURER 98-01

### Instruction Manual >

04-0131

Page 1 of 1

**Read all instructions carefully and completely before installing your new light bar. This light bar will work in conjunction with the Honda factory windshield.**

1. If you have a factory Honda windshield, you will need to remove it to install your light bar. Remove both front turn signal assemblies from the forks. Now remove the chrome turn signal lamps from the rubber stems. The gas tank must also be removed as the power wire for the light bar connects underneath the gas tank.
2. Install the chrome turn signal lamps onto the black turn signal adapters using the original screws.
3. Install the wire hold downs into the wire grooves on the light bars (3 on the left bar and 4 on the right) using the supplied Philips head screws. Place a small zip tie, for securing the wires later, below each one prior to tightening the screws.
4. Mount the light bars in the location that your original turn signal stems were mounted using the supplied 6mm x 16mm bolts.
5. Reinstall your windshield.
6. Install the turn signal assemblies onto the outside (small) holes on the Cobra light bars using the 1/4" x 3/8" button head Allen screws provided.
7. Install the spotlight with the longest wire on the left side light bar. Install the other spotlight on the right side light bar. Route the left spot light wire and left turn signal wires in the wire groove and tighten the zip ties.
8. Connect the 18" wire to one of the poles on the switch. It doesn't matter which one. The other end of the wire connects underneath the gas tank. This is the wire that will supply the power but don't connect it yet.
9. Twist the ends of the two spotlights together and insert them into the supplied push on connector and crimp with a wire crimp tool. Connect this wire to the other pole on your light bar switch.
10. Route the right turn signal wires and spotlight wires in the wire groove and tighten the zip ties.
11. Reconnect all your turn signal wires back into their original locations. Connect the black power wire from the light bar switch to the brown/white wire from the speedometer light wire loom, located under the gas tank, using the supplied blue quick splice connector.
12. Make sure that all your lighting is adjusted and working correctly and that there is no binding of any wires.

**\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0017 REV. B

06/01

**Anything's Possible.**