

Items Supplied >

- 1 – Freeway Bar
- 2 – 6mm x 14mm Hex Bolts
- 2 – 6mm Nylock Nuts
- 1 – Horn Relocater Bracket
- 1 – Spacer

Application >

VULCAN 800A/B 95-05

Instruction Manual >

01-1420

Page 1 of 1

1. Remove the horn bracket. Remove the front foot peg bracket bolts on both sides.
2. Install the Cobra freeway bar lower mounts on the foot peg bracket front boltholes. If using with stock foot pegs, place the supplied spacer on the left side in between the freeway bar and the foot peg bracket (you do not need the spacer if you are using these in conjunction with the Cobra floor boards).
3. Install freeway bar top mount using the stock hardware.
4. Install the horn on the supplied horn relocater bracket using the two 6x14mm hex bolts and nylock nuts provided. Remove the two stock nuts from the coil mount under the right side of the fuel tank. Install the horn and horn relocater bracket on the coil mount with horn facing down. Secure with the stock nuts.

Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*