

## Items Supplied >

- 1 - Sissy Bar W/Pad
- 2 - Brackets
- 4 - 6mm x 16mm Button Head Cap Screws
- 2 - 6mm x 25mm Button Head Cap Screws
- 2 - 6mm x 40mm Button Head Cap Screws
- 4 - 4 Spacers

## Application(s) >

KAWASAKI VN1500P 02-UP  
KAWASAKI VN1600B  
SUZUKI MARAUDER 1600

## Instruction Manual >

02-4962

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the (2) bolts from the fender rail.
2. Install left sissy bar bracket with the stamped part number towards the inside of motorcycle, place the 6mm x 40mm button head allen provided into the front hole with one of the (4) provided spacers between the sissy bar bracket and fender rail. Now install the 6mm x 25mm button head allen provided through the rear hole and place another spacer between the sissy bar bracket and fender rail, do not tighten bolts at this time.
3. Repeat step 2 on the right hand side.
4. Install sissy bar between the brackets using the (4) 6mm x 16mm button head allen provided.
5. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

**\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A  
03/03

**Anything's Possible.**

## Items Supplied >

- 1 - Sissy Bar W/Pad
- 2 - Brackets
- 4 - 6mm x 16mm Button Head Cap Screws
- 2 - 6mm x 25mm Button Head Cap Screws
- 2 - 6mm x 40mm Button Head Cap Screws
- 4 - 4 Spacers

## Application(s) >

KAWASAKI VN1500P

## Instruction Manual >

02-4962

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the (2) bolts from the fender rail.
2. Install left sissy bar bracket with the stamped part number towards the inside of motorcycle, place the 6mm x 40mm button head allen provided into the front hole with one of the (4) provided spacers between the sissy bar bracket and fender rail. Now install the 6mm x 25mm button head allen provided through the rear hole and place another spacer between the sissy bar bracket and fender rail, do not tighten bolts at this time.
3. Repeat step 2 on the right hand side.
4. Install sissy bar between the brackets using the (4) 6mm x 16mm button head allen provided.
5. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

**\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A  
03/03

**Anything's Possible.**