

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – SISSYBAR W/ PAD
- 2 – MOUNTS
- 4 – WASHERS
- 2 – M8 x 40mm BUTTONHEAD BOLTS
- 2 – M8 x 25mm BUTTONHEAD BOLTS
- 4 – M8 x 16mm BUTTONHEAD BOLTS

Application(s) >

HONDA REBEL 250

1996-2015

Instruction Manual >

02- 4605 / 02-5105 / 02-5605

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the (2) left and (2) right M8 fender rail bolts/nuts. Discard bolts, but save (2) M8 nuts.
2. Install left sissybar mount with part number facing inward. Insert the longer supplied M8x40mm bolt through the front mounting hole of sissybar mount, one supplied washer, fender rail/frame and into the stock M8 nut retained from Step 1. Insert the shorter M8x25mm bolt through rear mounting hole of sissybar mount, one supplied washer and into fender rail/frame. **DO NOT TIGHTEN** at this time. Repeat on Right Side.
3. Install the sissybar to the brackets using the (4) supplied M8x16mm bolts. Align sissybar and tighten all bolts.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
05/14

Anything's Possible.®

COBRA[®]

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – SISSYBAR W/ PAD
- 2 – MOUNTS
- 4 – WASHERS
- 2 – M8 x 40mm BUTTONHEAD BOLTS
- 2 – M8 x 25mm BUTTONHEAD BOLTS
- 4 – M8 x 16mm BUTTONHEAD BOLTS

Application(s) >

HONDA REBEL 250

1996-2015

Instruction Manual >

02- 4605 / 02-5105 / 02-5605

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the (2) left and (2) right M8 fender rail bolts/nuts. Discard bolts, but save (2) M8 nuts.
2. Install left sissybar mount with part number facing inward. Insert the longer supplied M8x40mm bolt through the front mounting hole of sissybar mount, one supplied washer, fender rail/frame and into the stock M8 nut retained from Step 1. Insert the shorter M8x25mm bolt through rear mounting hole of sissybar mount, one supplied washer and into fender rail/frame. **DO NOT TIGHTEN** at this time. Repeat on Right Side.
3. Install the sissybar to the brackets using the (4) supplied M8x16mm bolts. Align sissybar and tighten all bolts.

****Cobra[®] recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019
05/14

REV. A

Anything's Possible.[®]