

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

## Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 4 – M10 x 40 mm SS Buttonhead Bolts

## Application(s) >

[www.cobrausa.com](http://www.cobrausa.com)

- |                     |              |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750   | 2010-2015    |

## Instruction Manual >

02-6111B

**Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove your stock fender rail bolts.
2. Install your Cobra saddlebag supports using the supplied M10 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
3. Torque bolts to factory specifications.

**To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.**

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

## Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 4 – M10 x 40 mm SS Buttonhead Bolts

## Application(s) >

- |                     |              |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750   | 2010-2015    |

## Instruction Manual >

02-6111B

**Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove your stock fender rail bolts.
2. Install your Cobra saddlebag supports using the supplied M10 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
3. Torque bolts to factory specifications.

**To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.**

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
03/10

**Anything's Possible.®**