



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 2 – 6mm x 16mm Hex Bolts
- 2 – 6mm Nylock Nuts

Application(s) >

- Honda VT1100 87-96
- Honda ACE 1100 95-99
- Honda Spirit 1100 97-07

Instruction Manual >

02-6130

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your seat. Remove your rear fender using 12mm and 14mm sockets or wrenches to remove the six bolts which attach it to the fender rails.
2. Mount the rear bracket of your saddlebag supports to the 6mm studs on the inside of the fender rails.
3. Mount the front bracket of your saddlebag supports to the bottom of the fender rails and secure using the supplied 6mm bolts and nylock nuts.
4. Reinstall your rear fender and torque bolts to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
04/01

Anything's Possible.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 2 – 6mm x 16mm Hex Bolts
- 2 – 6mm Nylock Nuts

Application(s) >

- Honda VT1100 87-96
- Honda ACE 1100 95-99
- Honda Spirit 1100 97-07

Instruction Manual >

02-6130

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your seat. Remove your rear fender using 12mm and 14mm sockets or wrenches to remove the six bolts which attach it to the fender rails.
2. Mount the rear bracket of your saddlebag supports to the 6mm studs on the inside of the fender rails.
3. Mount the front bracket of your saddlebag supports to the bottom of the fender rails and secure using the supplied 6mm bolts and nylock nuts.
4. Reinstall your rear fender and torque bolts to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
04/01

Anything's Possible.