

Items Supplied >

- 1 – Set Of Plated Saddle Bag Supports
- 2 – 8 x 40mm Button Head Bolts
- 2 – 10 x 50mm Button Head bolts
- 2 – Small Spacers
- 2 – Large Spacers

Application(s) >

Honda VTX1300R/S 03-06
VTX1800R/S 02-07

Instruction Manual >

02-6160

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts.
2. Place the supplied spacers in the recessed holes on the fender rails (large spacer to the front, small spacer to the rear).
3. Install your Cobra saddlebag supports using the supplied button head bolts (where the stock bolts were removed) the saddlebag supports should hang towards the rear and away from the motorcycle.
4. Torque bolts to factory specifications.
Note: If to be used in combination with a Cobra sissy bar, mount the saddlebag supports over the sissy bar brackets and do not use the supplied spacers.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A
03/07

Anything's Possible.

Items Supplied >

- 1 – Set Of Plated Saddle Bag Supports
- 2 – 8 x 40mm Button Head Bolts
- 2 – 10 x 50mm Button Head bolts
- 2 – Small Spacers
- 2 – Large Spacers

Application(s) >

Honda VTX1300R/S 03-06
VTX1800R/S 02-07

Instruction Manual >

02-6160

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts.
2. Place the supplied spacers in the recessed holes on the fender rails (large spacer to the front, small spacer to the rear).
3. Install your Cobra saddlebag supports using the supplied button head bolts (where the stock bolts were removed) the saddlebag supports should hang towards the rear and away from the motorcycle.
4. Torque bolts to factory specifications.
Note: If to be used in combination with a Cobra sissy bar, mount the saddlebag supports over the sissy bar brackets and do not use the supplied spacers.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019 REV. A
03/07

Anything's Possible.