

#### Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 4 M8 Spacers
- 4 M8 x 40 mm SS Buttonhead Bolts

# Application(s) >

YAMAHA V-STAR 1300 07-15

#### Instruction Manual >

02-6245

www.cobrausa.com

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- Remove your stock fender rail bolts.
- Place the supplied spacers in the front and rear recessed holes on the fender rails.
- Install your Cobra saddlebag supports using the supplied M8 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
- Torque bolts to factory specifications.

\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

### Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 4 M8 Spacers
- 4 M8 x 40 mm SS Buttonhead Bolts

## Application(s) >

YAMAHA V-STAR 1300 07-15

#### Instruction Manual >

02-6245

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- 1. Remove your stock fender rail bolts.
- 2. Place the supplied spacers in the front and rear recessed holes on the fender rails.
- 3. Install your Cobra saddlebag supports using the supplied M8 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
- 4. Torque bolts to factory specifications.

\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

www.cobrausa.com