

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 2 – 8mm x 45mm Button Head Bolts
- 2 – 8mm x 50mm Button Head Bolts
- 2 – Thick Spacer
- 2 – Thin Spacer

Application(s) >

Yamaha RoadLiner 06-14

Instruction Manual >

02-6260

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove the (2) left M8 bolts from fender support / rear fender and discard. Insert one of the longer supplied M8 bolts through the front mount of the saddlebag support (short leg of support forward), supplied thick spacer, and into fender rail / fender. Insert one of the shorter supplied M8 bolts through rear mount of support, thin spacer and into rear fender support / fender and snug tight. Repeat on the right side.
2. Torque bolts to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A

11/08

Anything's Possible.®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Left Saddlebag Support
- 1 – Right Saddlebag Support
- 2 – 8mm x 45mm Button Head Bolts
- 2 – 8mm x 50mm Button Head Bolts
- 2 – Thick Spacer
- 2 – Thin Spacer

Application(s) >

Yamaha RoadLiner 06-14

Instruction Manual >

02-6260

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove the (2) left M8 bolts from fender support / rear fender and discard. Insert one of the longer supplied M8 bolts through the front mount of the saddlebag support (short leg of support forward), supplied thick spacer, and into fender rail / fender. Insert one of the shorter supplied M8 bolts through rear mount of support, thin spacer and into rear fender support / fender and snug tight. Repeat on the right side.
2. Torque bolts to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019
11/08

REV. A

Anything's Possible.®