



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 4 – Bungee Knobs
- 2 – Screws, M8 x 70 mm S.S. BHSC
- 2 – Screws, M8 x 95 mm S.S. SHSC

### Application(s) >

- |                        |             |
|------------------------|-------------|
| Suzuki Boulevard M109R | 2006 - 2014 |
| Suzuki Boulevard M90   | 2009        |

### Instruction Manual >

02-7345

1. Remove the stock front M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 95 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
2. Remove the stock rear M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 70 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
3. With all components aligned and installed, tighten the buttonhead screws to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. B

04/09

**Anything's Possible®**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 4 – Bungee Knobs
- 2 – Screws, M8 x 70 mm S.S. BHSC
- 2 – Screws, M8 x 95 mm S.S. SHSC

### Application(s) >

- |                        |             |
|------------------------|-------------|
| Suzuki Boulevard M109R | 2006 - 2014 |
| Suzuki Boulevard M90   | 2009        |

### Instruction Manual >

02-7345

1. Remove the stock front M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 95 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
2. Remove the stock rear M8 screws retaining the chrome fender rail / fender on each side of the rear fender. Replace these screws with two bungee knobs and supplied M8 x 70 mm buttonhead screws. Do not tighten the screws completely at this time. The stock screws will not be reused.
3. With all components aligned and installed, tighten the buttonhead screws to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*