



® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 20mm Buttonhead Bolts

Application(s) >

- | | |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750 | 2010-2014 |

Instruction Manual >

02-7611 / 02-8611

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely. The stamped numbers on the brackets will face inward.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 20mm Button Head bolts then tighten all hardware.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***



® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 20mm Buttonhead Bolts

Application(s) >

- | | |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750 | 2010-2014 |

Instruction Manual >

02-7611 / 02-8611

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely. The stamped numbers on the brackets will face inward.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 20mm Button Head bolts then tighten all hardware.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***