

Items Supplied >

- 1 Sissy Bar w/pad
- 2 Brackets
- 4 8mm x 25mm Button Head Bolts
- 4 8mm x 20mm Button Head Bolts

Application(s) >

ACE 1100 95-99

ACE Tourer 98-01

VT1100 Shadow 87-96

VT1100 Spirit 97-07

VT1100 Sabre 00-07

Instruction Manual >

02-7635 / 02-8635

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

- 1. Remove the two (2) rear bolts on each fender rail first on the right side.
- 2. Install the brackets on the outside of the fender rail with the bent portion of the bracket facing towards the inside (part number) using the supplied M8 x 25 mm bolts. Repeat on the left side
- 3. Install the sissy bar to the brackets using the M8 x 20 mm bolts. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

07/08 REV. A

Anything's Possible.

COBRA

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Sunnlied >

- 1 Sissy Bar w/pad
- 2 Brackets
- 4 8mm x 25mm Button Head Bolts
- 4 8mm x 20mm Button Head Bolts

Annlication(s) >

www.cobrausa.com

www.cobrausa.com

ACE 1100 95-99

ACE Tourer 98-01

VT1100 Shadow 87-96

VT1100 Spirit 97-07

VT1100 Sabre 00-07

Instruction Manual >

02-7635 / 02-8635

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

- 1. Remove the two (2) rear bolts on each fender rail first on the right side
- 2. Install the brackets on the outside of the fender rail with the bent portion of the bracket facing towards the inside (part number) using the supplied M8 x 25 mm bolts. Repeat on the left side.
- 3. Install the sissy bar to the brackets using the M8 x 20 mm bolts. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A