



TM 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Sissy Bar w/pad
- 2 – Brackets
- 4 – M8 x 20mm Button Head Screws
- 2 – M10 x 60mm Button Head Screws
- 2 – M10 x 65mm Button Head Screws
- 4 – Flat Washers

Application(s) >

Suzuki Boulevard C109R 2008-2009

Instruction Manual >

02-7850 / 02-8850

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time

1. Remove the stock fender rail allen bolts from the left fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10 x 60mm screw thru the bracket, washer and into the fender rail. Insert the M10 x 65mm screw thru the bracket, washer and into the rear hole of the fender rail. **Do not tighten at this time.**
2. Repeat Step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied M8 x 20mm button head screws.
4. Tighten all hardware, torque the screws installed in the fender rail to factory specifications.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019REV. B

07/08

Anything's Possible™



TM 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – Sissy Bar w/pad
- 2 – Brackets
- 4 – M8 x 20mm Button Head Screws
- 2 – M10 x 60mm Button Head Screws
- 2 – M10 x 65mm Button Head Screws
- 4 – Flat Washers

Application(s) >

Suzuki Boulevard C109R 2008-2009

Instruction Manual >

02-7850 / 02-8850

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time

1. Remove the stock fender rail allen bolts from the left fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10 x 60mm screw thru the bracket, washer and into the fender rail. Insert the M10 x 65mm screw thru the bracket, washer and into the rear hole of the fender rail. **Do not tighten at this time.**
2. Repeat Step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied M8 x 20mm button head screws.
4. Tighten all hardware, torque the screws installed in the fender rail to factory specifications.

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

DOCUMENT NO. 0019REV. A

07/08

Anything's Possible™