® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Supplied >

1 - 20" Wire with Push On Connector

OBRA

- 1 Push On Connector
- 1 Blue Quick Splice Connector

Application(s) >

YAMAHA V-STAR 650 CLASSIC 98-10

www.cobrausa.com

Instruction Manual >	04-0201	Page 1 of 1

Read your installation instructions completely before beginning. This light bar can be installed in just a few minutes using common tools. It is recommended however, that a qualified mechanic or technician install this product.

- 1. Your Boulevard Light Bar comes with everything you need to mount and wire it to your motorcycle. After unpacking the light bar, you will need to turn the spotlights around 180 degrees. They are facing backwards for packaging purposes only.
- 2. Unplug your turn signals and remove them from their original mounts. Mount them to the aluminum fittings underneath the light bar using the stock turn signal mounting screw. Now remove the original turn signal mounts and set them aside. Remove the turn signal mount bar.
- 3. Install your Boulevard Products Light Bar on the lower triple tree using the original turn signal mounting hardware. Align the assembly and tighten the two bolts to factory torque specs. Align the turn signals and spotlights. Check to make sure the screws on top of the light bar frame that hold the turn signal adapters are snug.
- 4. Connect the 14" wire to one of the poles on the switch. It doesn't matter which one. Route the other end of the wire into the back of the headlight housing. Attach the wire from the switch to the blue running light wire using the blue quick splice clip supplied. Twist the ends of the two spotlights together and insert them into the supplied push on connector and crimp with a wire crimp tool. Connect this wire to the other pole on your light bar switch.
- 5. Plug your turn signal wires back into their original location. Reinstall the headlight bulb assembly back into its housing. Check to make sure your handlebars turn lock to lock without any stretching or binding of any wires. Check the alignment of all your lighting. Make sure everything is working properly before riding.

* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.