



www.cobrausa.com

Items Supplied >

- 1 Lightbar Assembly
- 1 20" Wire
- 2 Push On Connectors
- 1 Blue Quick Splice Connector
- 3 Cable Ties

Application(s) >

SUZUKI VOLUSIA 800 03-04 BOULEVARD C50 05-06

Instruction Manual >

04-0326

Page 1 of 1

Read your installation instructions completely before beginning. It is recommended however, that a qualified mechanic or technician install this product.

- 1. Your light bar comes with everything you need to mount it to your motorcycle. After unpacking the light bar, you will need to turn the spotlights around 180 degrees. They are facing backwards for packaging purposes only.
- 2. Remove your headlight assembly and unplug the turn signals.
- 3. Remove the turn signal mount from the lower triple clamp.
- 4. Remove the turn signals from the turn signal mount and install them onto the Cobra light bar using the stock screws.
- 5. Mount the light bar to the lower triple clamp using the stock bolts.
- 6. Connect both spotlight wires to one side of the switch using the supplied crimp connector.
- 7. Connect the supplied power wire from the switch to the orange/blue accessory wire inside the headlight housing using the supplied (blue) quick splice connector.
- 8. Connect the Cobra turn signals to the stock turn signal connectors. The stock black turn signal connector gets connected to the right turn signal and the grey turn signal connector gets connected to the left. The blue wires from the turn signals get connected to the orange/green wires.
- 9. Reinstall the head light with the stock hardware.
- 10. Check to make sure that your handlebars turn lock to lock without any stretching or binding of any wires. Check the alignment of all your lighting. Make sure everything is working properly before riding.

^{*} Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.