

Items Supplied >

- 2 - Black Injected Molded Turn Signal Adaptor
- 2 - Black Adaptor Plates
- 2 - 1/4" x 1" Hex Bolts
- 2 - 1/4" Flat Washers
- 2 - Aluminum Spacers

Application(s) >

- VT1100 87-96
- VT1100 SPIRIT 97-02
- ACE 1100 95-99

Instruction Manual >

04-3120

Page 1 of 1

1. Remove your stock rear turn signal assemblies noting where they plug in. Do one side at a time.
2. Loosen the stock fender rail assembly. Remove the metal plate between the rubber grommet and the fender.
3. Place the supplied bolt, washer and the aluminum spacer through the front hole in the rubber grommet from the inside between the fender rail and the fender.
4. Install the Boulevard spacer plate between the rubber grommet and the supplied turn signal adaptor. Thread the bolt into the turn signal adaptor and tighten. Be careful not to over tighten.
5. Remove the screw from your stock turn signal and remove the turn signal from the stock stem. Feed the wires through the Boulevard adaptor hole and install your turn signal onto the new mount using your stock screw.
6. Plug the wires back into their original position. **Check to make sure everything is tight and all lighting is working properly before riding.**

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*