



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 1 – Set Of Floorboards And Mounts
- 4 – M8x30mm Allen Bolts

**Application(s) >**

- SUZUKI VOLUSIA 800 01-04
- SUZUKI BOULEVARD C50 05-08
- SUZUKI BOULEVARD M50 05-08

**Instruction Manual >**

06-3825/06-4825

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the bolts securing the rear foot peg mounts to the frame.
2. Remove the passenger foot peg and brackets.
3. Secure the floorboard assemblies using the supplied hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
10/09

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 1 – Set Of Floorboards And Mounts
- 4 – M8x30mm Allen Bolts

**Application(s) >**

- SUZUKI VOLUSIA 800 01-04
- SUZUKI BOULEVARD C50 05-08
- SUZUKI BOULEVARD M50 05-08

**Instruction Manual >**

06-3825/06-4825

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the bolts securing the rear foot peg mounts to the frame.
2. Remove the passenger foot peg and brackets.
3. Secure the floorboard assemblies using the supplied hardware.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
10/09

**Anything's Possible.**