

## Items Supplied >

2 – Floorboards with Rubber  
2 – Black Mounts  
2 – M10 x 45mm Allen Bolts  
2 – M10 Flat Washers  
2 – M10 Nylock Nuts  
2 – Pins  
4 – Springs  
4 – Nylon Balls  
2 – 6MM Washers

## Application(s) >

KAWASAKI VULCAN1500D/E/J/N/P 96-08  
KAWASAKI VULCAN1600A/B 03-08  
SUZUKI MARAUDER 1600 2004

## Instruction Manual >

06-3945/06-3960/06-3961

Page 1 of 1

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove your original passenger foot pegs and their mounts from the frame.
2. Before assembling the floorboards to their mounts, bolt the floorboard mounts to the motorcycle using the supplied M10 Allen bolt, flat washers, and nylock nuts.
3. To install the floorboards to their mounts, first place a nylon ball onto each of the two holes on the top of the mount. Now insert one spring into each of the two holes, which are drilled into the side of the floorboard itself. A small amount of grease applied to both ends of the springs will help keep them in place.
4. Carefully place the floorboard with springs on top of the nylon balls. With the floorboard in the up position, gently press down on it to compress the springs. With the springs compressed, slide the provided pins through the floorboards and their mounts. Place the supplied 6mm washer onto the pin and install the cotter pin.
5. Check to make sure that the cotter pins are properly installed and bolts are tight prior to riding the motorcycle.

**\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**