



**Items Supplied >**

- 2 - 6mm x 35mm B.H.C.S
- 2 - 6mm Nylock Hex Nuts
- 4 - 6mm Flat Washers
- 1 - Set Of Floorboards And Mounts

**Application(s) >**

HONDA SPIRIT 750-C2	07-09
HONDA AERO 750	04-09
HONDA PHANTOM 750	2010

**Instruction Manual >**

06-3611 / 06-4611 / 06-3618 / 06-4618

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard assemblies into these locations using the supplied hardware. Torque to factory specification.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
11/08

**Anything's Possible.®**



**Items Supplied >**

- 2 - 6mm x 35mm B.H.C.S
- 2 - 6mm Nylock Hex Nuts
- 4 - 6mm Flat Washers
- 1 - Set Of Floorboards And Mounts

**Application(s) >**

HONDA SPIRIT 750-C2	07-09
HONDA AERO 750	04-09
HONDA PHANTOM 750	2010

**Instruction Manual >**

06-3611 / 06-4611 / 06-3618 / 06-4618

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove the two bolts on each side of your motorcycle that mount the passenger pegs to the frame.
2. Install the passenger floorboard assemblies into these locations using the supplied hardware. Torque to factory specification.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
11/08

**Anything's Possible.®**