

## Items Supplied >

- 2 - Floorboard Assemblies with Mounts
- 2 - 8mm x 45mm Hex Bolts
- 2 - 8mm Nylock Nuts
- 4 - 8mm Flat Washers

## Application(s) >

VULCAN 2000 04-10

## Instruction Manual >

06-3963 / 06-4963

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts.
3. Check to make sure that all hardware is properly installed and the bolts are tight prior to riding the motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
11/08

**Anything's Possible.®**

## Items Supplied >

- 2 - Floorboard Assemblies with Mounts
- 2 - 8mm x 45mm Hex Bolts
- 2 - 8mm Nylock Nuts
- 4 - 8mm Flat Washers

## Application(s) >

VULCAN 2000 04-10

## Instruction Manual >

06-3963 / 06-4963

**Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.**

1. Remove your original passenger foot pegs from their mounts.
2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied 8mm bolts, washers and nylock nuts.
3. Check to make sure that all hardware is properly installed and the bolts are tight prior to riding the motorcycle.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
11/08

**Anything's Possible.®**