

Items Supplied >

- 1 - Front Muffler
- 1 - Rear Muffler
- 2 - 5/16" x 3/4" Bolts
- 2 - 5/16" Hex Nuts
- 2 - 5/16" Flat Washers
- 2 - 5/16" Lock Washers
- 1 - 8mm Nylock Hex Nut

Application >

HONDA SPIRIT 1100 97-07

Instruction Manual >

1170/1170SC/1170TO

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove your stock mufflers and heat shields.
2. Install the stock gaskets onto the head pipes and the stock clamps onto the Boulevard Mufflers.
3. Slightly loosen the rear head pipe.
4. Install the Boulevard Mufflers onto the head pipes and bolt together using the supplied hardware.
5. Bolt the lower muffler to the stock mount using the stock bolt and the supplied 8mm nut.
6. Check mufflers for clearance and tighten all bolts.
7. Reinstall the heat shields.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-1270.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*