

Items Supplied >

- 1 - Front Muffler
- 1 - Rear Muffler
- 2 - T-Bolt Clamps
- 1 - 5/16" x 3/4" Hex Bolt
- 1 - 5/16" Lock Washer
- 1 - 5/16" Flat Washer

Application >

YAMAHA VIRAGO 750/1100

Instruction Manual >

2165/2165SC/2165TO

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove stock mufflers and front head pipe.
2. Remove the stock center stand rubber grommet and install onto the rear muffler.
3. Bolt new muffler assembly together using supplied hardware and install on bike sliding bottom muffler over the stock head pipe first and using the stock gasket. Secure muffler using supplied clamp.
4. Re-install front head pipe sliding it into the top muffler (no gasket required). Secure muffler using supplied clamp.
5. Make sure alignment is correct and that no parts are in a bind. Tighten all bolts then tighten all clamps.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-2165.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*