

Items Supplied >

- 1 - Front Muffler
- 1 - Rear Muffler
- 2 - 10mm Flat Washers
- 2 - #268-55 Clamps

Application >

YAMAHA V-STAR 1100 99-03 (All), 04-05 Non California Models

Instruction Manual >

2167/2167SC/2167TO/2267

Page 1 of 1

PRIOR TO INSTALLATION OF SLIP ON MUFFLERS, PLEASE READ INSTRUCTIONS FULLY.

1. Loosen clamps and remove stock mufflers from headpipes. **DO NOT LOOSEN STOCK HEAD PIPES.**
2. Make sure the stock gaskets are removed from the rear of the stock head pipes.
3. Slide the Cobra Mufflers onto the stock head pipes using the supplied clamps the gaskets will not be used.
4. Using the stock exhaust mounting bolts with the supplied 10mm flat washers, bolt the pipes to the frame but **DO NOT TIGHTEN.**
5. Check alignment of mufflers with each other be sure they are parallel and tighten the bolt, then the clamp on each muffler.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-2170.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*