

Items Supplied >

- 1 - Right/Top Muffler
- 1 - Right/Bottom Muffler
- 1 - Left/Top Muffler
- 1 - Left/Bottom Muffler
- 2 - 5/16" x 3/4" Hex Bolts
- 2 - 5/16" Lock Washers
- 2 - 5/16" Flat Washers
- 2 - 10mm Hex Nuts
- 4 - #268-55 Clamps

Application >

YAMAHA V-MAX THRU 2008

Instruction Manual >

2168SC

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove stock mufflers.
2. Remove center stand (this will not be reinstalled).
3. Install the top left and top right mufflers first and **FINGER TIGHTEN**. Make sure lead in tube cover slips over stock chrome heat shield.
4. Install bottom left and bottom right mufflers using hardware supplied and **FINGER TIGHTEN**.
5. Check all clearances and tighten top muffler bolts and clamps. Then, tighten bottom bolts and clamps.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-2168.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*