

Items Supplied >

- 1 – Front Muffler
- 1 – Rear Muffler
- 2 – 5/16" x 3/4" Hex Bolts
- 2 – 5/16" Hex Nuts
- 2 – 5/16" Lock Washers
- 2 – 5/16" Flat Washers
- 2 – #268-62 T-Bolt Clamps
- 1 – 2" Heat Shield

Application >

KAWASAKI VULCAN 1500A/C 87-00

Instruction Manual >

4165/4165SC/4165TO

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove the stock mufflers, left head pipe and collector box.
2. Reinstall left head pipe only.
3. Slightly loosen right head pipe but **DO NOT REMOVE**.
4. Install the rear muffler onto the left head pipe using the supplied clamp and the stock mounting bolt. **DO NOT TIGHTEN**.
5. Slide the front muffler onto the right head pipe and align the bolt holes with the rear muffler. Install the two (2) bolts, lock washers, flat washers, and hex nut but **DO NOT TIGHTEN**.
6. Adjust front and rear head pipe so that they are properly aligned. All mounting points should align so that there is no binding or tension on them. This is very important.
7. Check the muffler for proper clearance and then tighten all the bolts, clamps and the foot peg bolt.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-4165.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*